

①  [socomec](http://socomec.com) www
Technical support/Product software



NET VISION

quick start guide for Windows®


②  Net Vision 8

<https://socomec.co.uk/en-gb/net-vision-8-ups-websnmp-ethernet-card-iot-gateway>

③  NetVision Explorer 



	Name	Location	IP	Action	F/W Ver.	Model	MAC
<input type="checkbox"/>			xxx.xxx.xxx.xxx	   	8.00	Net card	xx-xx-xx-ff-c4-3a



⑤

USB + HyperTerminal
COMx : 9600,N,8



login: admin
password: FFC43A

~~DHCP~~
IP = 192.168.7.18

⑥ Click  Browse → http://IP

⑦

login

admin

MAC : xx xx xx **FFC43A**

Username

Password

Connect

⑧

Please Change Password

Enter New PASSWORD

Password

MAC: FFC43A = example

12 Char min A-Z a-z 0-9 !#%&